




BONESOUNDZ

ZX6 Bone Conduction wireless Headset
USER MANUAL

FOR EXCELLENT CUSTOMER
SUPPORT VISIT:
easycustomersupport.com



① Power on/off ② "+" Next ③ "-" Previous

④ Microphone ⑤ Indicator light

⑥ Magnetic charging port


⑦ Data transfer & charging cable

Packing list:

1. Headset*1

2. User manual*1

3. Charging cable*1



Power on /off:

Press and hold the on/off button for about 3 seconds, when the indicator light flashes red and blue alternately, the headset has been turned on/off.

Pairing Method:

*keep the headphone within 3 feet of the device you want to connect to if it's the first time connecting

*When the red and blue light flash alternately it means the headphone is in pairing mode.

*Open your smart device, go to settings, and bluetooth settings, and find "Bone Conduction ZX6" from the device list. Tap on the connection. When the blue light flashes slowly the ZX6 is being connected successfully.

How to switch between BT mode and MP3 mode?

The ZX6 can store songs and entertainment directly on the headphone's built in storage. You can switch between the mode to play entertainment from the internal storage and the mode to connect to your smart device.

The headset is in Bluetooth mode by default. Press the "power on" button twice in a row to switch to MP3 mode. Double pressing the "power on" button again will switch back to Bluetooth mode.

How to charge the headphone ?

The battery capacity of the headphone will be displayed on the phone.

When the headset prompts "Low power", it indicates that the battery is low, please charge the headphone promptly.

The magnetic charging port is designed to ensure proper connection. If it does not automatically magnetize closed, please check if it is in the correct position.

How to download or cancel the songs?

Your computer can be connected to the headset through the magnetic charging cable.

Once connected you will see the headphones appear on your computer desktop as a folder you can open. At that time you can drag songs or other audio files into the folder for playback.

Basic Operations

Basic Operations

BT MODE

Functions	States	Action
Power on/off	Off/on	Press and hold Power button for 3s
Siri	Play	Press and hold the + button for 2s
Pause/play	Play/pause	Short Press of the power button
Next song	Play	Press the + button twice in a row
Previous song	Play	Press the - button twice in a row
Answer/ Reject	Call status	Press "power on/off" button one time
Volume + /- Play		press + or - button

MP3 MODE

Functions	States	Action
Switch mode	BT/MP3	Press the "power on/off" button twice in a row
Pause/play	Play/pause	Press the "power on" button
Volume+	Play	press + button
Volume-	Play	press - button
Next /Previous	Play	Press the +- button twice in a row

LED Indicator

Functions	Action
Blue and red light alternate flashing:	Waiting for BT pairing
Blue light flashing slowly:	BT mode connected
Blue light flashing:	data transfer mode
Green light flashing:	Ready to play in MP3 mode

Water Resistance Note:

The headphones are water resistant to a maximum of 3 feet for up to 30 minutes. For best reliability, limit the exposure to being submerged in water.

Model:ZX6

BT version: 5.3

Microphone sensitivity: -42dB

Support: HSP/HFP/A2DP/ AVRCPConnect distance: 10m/
33ft Battery capacity: 180mAh

Built-in memory: 16G

Standby time: About 240 hours

Charging time: About 2 hours Waterproof: IP68

Charging voltage: 5V

Input: DC5V/ 100mA

Standard Limited Warranty

The Limited warranty set forth below is given by ClearView Productions with respect to the audio product that you have purchased. The product that you have purchased is the only product to which this warranty card and the limited warranty, provided by ClearView Productions will apply. Your product, when delivered to you in new condition in its original container, is warranted against defects in materials or workmanships for a period of three (3) months from the date of original purchase and determined to be defective upon inspection, will be exchanged for new or refurbished product, as determined by the manufacturer. Warranty repair or replacement shall not extend the original warranty period of the defective product. The limited warranty does not cover any supplies or accessories unless defective.

This limited warranty shall only apply if the product is used in conjunction with compatible equipment and compatible software, as to which items ClearView Productions shall have no responsibility.

This limited warranty covers all defects encountered in normal use of the product, and does not apply in the following cases (a) Loss of or damage to the product due to abuse, mishandling, or improper packaging by you, alteration, accident, electrical current fluctuations, failure to follow operating, maintenance or environmental instructions prescribed in ClearView Productions instructions manual. Use of parts or supplies (other than those sold by ClearView Productions) that cause damage to the product or cause abnormally frequent service calls or service problems is prohibited. Any attempts to open, service, or tamper with the ClearView Productions device shall void the warranty.

NO IMPLIED WARRANTY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, APPLIES TO THE PRODUCT AFTER EXPIRY OF THE APPLICABLE PERIOD OF THE EXPRESS LIMITED WARRANTY STATED ABOVE. All inquiries with regards to the product warranty may be directed to customer support by visiting easycustomersupport.com

NO OTHER EXPRESS WARRANTY OR GUARANTY, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BIND CLEARVIEW PRODUCTIONS. (SOME PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU)

CLEARVIEW PRODUCTIONS SHALL NOT BE LIABLE FOR LOSS OF REVENUES OR PROFITS, [INCONVENIENCE, EXPENSE FOR SUBSTITUTE EQUIPMENT OR SERVICE, STORAGE CHARGES, LOSS OR CORRUPTION OF DATA, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE OR MISUSE OF, OR INABILITY TO USE THE PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF ClearView Productions HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. IN NO EVENT SHALL RECOVERY OF ANY KIND AGAINST CLEARVIEW PRODUCTIONS BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY CLEARVIEW PRODUCTIONS, WHICH CAUSED THE ALLEGED DAMAGE WITHOUT LIMITING THE FOREGOING. YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF USE OR MISUSE OF, OR INABILITY TO USE THE PRODUCT NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF CLEARVIEW PRODUCTIONS (SOME PROVINCES/STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLPY TO YOU) THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THE PRODUCT, OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT, AND STATES YOUR EXCLUSIVE REMEDY.